

D6 RS485 - RJ45 - (NET)

INSTALLATION GUIDE

COPYRIGHT

Electrex is a trademark of Akse S.r.l. All rights reserved.
It is forbidden to duplicate, adapt, transcript this document without Akse written authorization, except when regulated accordingly by the Copyright Laws.

WARRANTY

This product is covered by a warranty against material and manufacturing defects for a 24 months period from the manufacturing date.

The warranty does not cover the defects that are due to:

- Negligent and improper use
- Failures caused by atmospheric hazards
- Acts of vandalism
- Wear out of materials
- Firmware upgrades

Akse reserves the right, at its discretion, to repair or substitute the faulty products

The warranty is not applicable to the products that will result defective in consequence of a negligent and improper use or an operating procedure not contemplated in this manual.

RETURN AND REPAIR FORMALITIES

Akse accepts the return of instruments for repair only when authorized in advance. The transport costs are at customer charge.

RE-SHIPING OF REPAIRED PRODUCT

The terms for re-shipment of repaired products are ex-works, i.e. the transport costs are at customer charge.

Products returned as defective but found to be perfectly working by our laboratories, will be charged a flat fee to account for checking and testing time irrespective of the warranty terms.

SAFETY

This instrument was manufactured and tested in compliance with IEC 61010-1 CAT III - 300V class 2 standards for operating voltages up to 300 VAC rms phase to neutral.

In order to maintain this condition and to ensure safe operation, the user must comply with the indications and markings contained in the following instructions:

- When the instrument is received, before starting its installation, check that it is intact and no damage occurred during transport.
- Before mounting, ensure that the instrument operating voltages and the mains voltage are compatible then proceed with the installation.
- The instrument power supply needs no earth connection.
- The instrument is not equipped with a power supply fuse; a suitable external protection fuse must be foreseen by the contractor.
- Maintenance and/or repair must be carried out only by qualified, authorized personnel
- If there is ever the suspicion that safe operation is no longer possible, the instrument must be taken out of service and precautions taken against its accidental use.

Operation is no longer safe when:

- There is clearly visible damaged.
- The instrument no longer functions.
- After lengthy storage in unfavorable conditions.
- After serious damage occurred during transport

The instruments must be installed in respect of all the local regulations.

OPERATOR SAFETY

Warning: Failure to observe the following instructions may lead to a serious danger of death.

- During normal operation dangerous voltages can occur on instrument terminals and on voltage and current transformers. Energized voltage and current transformers may generate lethal voltages. Follow carefully the standard safety precautions while carrying out any installation or service operation.
- The terminals of the instrument must not be accessible by the user after the installation. The user should only be allowed to access the instrument front panel where the display is located.
- Do not use the digital outputs for protection functions nor for power limitation functions. The instrument is suitable only for secondary protection functions.
- The instrument must be protected by a breaking device capable of interrupting both the power supply and the measurement terminals. It must be easily reachable by the operator and well identified as instrument cut-off device.
- The instrument and its connections must be carefully protected against short-circuit.

Precautions: Failure to respect the following instructions may irreversibly damage to the instrument.

- The outputs and the options operate at low voltage level; they cannot be powered by any unspecified external voltage.
- The application of currents not compatible with the current inputs levels will damage to the instrument.

Further documentation may be downloaded from our web site www.electrex.it.

This document is owned by company AKSE that reserves all rights.

DECLARATION OF CONFORMITY

Akse hereby declares that its range of products complies with the following directives EMC 2014/30/EU, 2014/35/EU and complies with the following product's standard CEI EN 61326 - Ed. 2.0 (2012) - IEC 61326 - Ed. 2.0 (2012) CEI EN 61010 Ed. 3 (2010) - IEC 61010 Ed. 3 (2010). The product has been tested in the typical wiring configuration and with peripherals conforming to the EMC directive and the LV directive.

READINGS



Keep pressed for 2 seconds to display:
- Type of instrument
- Firmware version
- Serial number
- RS485 address

MEASURE LIST TABLE

(The parameters available vary according to instrument configuration)

Short Keypress	Long Keypress	Long Keypress			
		P	Q	S	PF
UL-N	I	P	Q	S	PF
U L-L	I ∑	P ∑	Q ∑	S ∑	PF ∑
U THD L-N	I THD	P Avg Imp	Q Avg Imp	S Avg Imp	
U THD L-L	I THD ∑	P Avg Exp	Q Avg Exp	S Avg Exp	
U L-N Min	I Max	P MD Imp	Q MD Imp	S MD Imp	
U L-L Min	I AVG	P MD Exp	Q MD Exp	S MD Exp	
U L-N Max	I MD				
U L-L Max					

Short Keypress	Long Keypress				
	Ea + MAIN	Er + L MAIN	Er + C MAIN	Es + MAIN	t LIFE
Ea - MAIN	Er - L MAIN	Er - C MAIN	Es - MAIN	t MAIN	
Ea Phase	Er L Phase	Er C Phase	Es Phase	t P1	
Ea + Phase	Er + L Phase	Er + C Phase	Es + Phase	t P2	
Ea - Phase	Er - L Phase	Er - C Phase	Es - Phase	t P3	
Ea + P1	Er + L P1	Er + C P1	Es + P1		
Ea - P1	Er - L P1	Er - C P1	Es - P1		
Ea + P2	Er + L P2	Er + C P2	Es + P2		
Ea - P2	Er - L P2	Er - C P2	Es - P2		
Ea + P3	Er + L P3	Er + C P3	Es + P3		
Ea - P3	Er - L P3	Er - C P3	Es - P3		

LEGEND OF PARAMETERS AND SYMBOLS

U	Voltage	L-N	Phase-Neutral
I	Current	L-L	Phase-Phase
P	Active Power	THD	Total Harmonic Distortion
Q	Reactive Power	Min	Minimum values (10 cycles time base)
S	Apparent Power	Max	Maximum values (10 cycles time base)
PF	Power Factor	Avg	Average (rolling) value
Ea	Active Energy	MD	Maximum Demand
Er	Reactive Energy	∑ / MAIN	Value (total)
Es	Apparent Energy	P	Value (partial)
L	Inductive	t	Time counter
C	Capacitive	LIFE	Operating time
Imp / +	Imported value		
Exp / -	Exported value		

MECHANICAL CHARACTERISTICS

Case	Self-extinguishing plastic material class V0
Protection degree	IP40 on front panel, IP20 terminals side
Size	105 x 90 x 58 mm (6 DIN modules)
VOLTAGE INPUTS	
Direct insertion	Up to 300 Vrms phase-neutral or 520 Vrms phase to phase
With external VT:	Primary: programmable (max. 400 kV) Secondary: programmable (max. 300 V)
	Overload: 900 Vrms phase to phase for 1 sec
Aux. power supply	85+265Vac +/- 10% 50/60Hz
Self consumption:	< 2,5VA

MODELS

PFNK6-1Q7D9-0MM, PFK6-1Q5D9-121, PFK6-1Q5D9-A21, PFK6-1Q5D9-F21
PFNE6-1H7D9-0M0, PFNE6-1H5D9-110, PFNE6-1H5D9-A10, PFNE6-1H5D9-F10
PFN66-EH7D9-0M0, PFN66-EH5D9-110, PFN66-EH5D9-F10, PFK6-1Q7D9-0M0,
PKA0212-00

DEVICE SETUP

DESCRIPTION OF KEYS

	Short keypress	Long keypress		Short keypress	Long keypress
	Confirm parameter	Setup confirmation		Go to previous value	Go to previous page
	Modify parameter			Go to next value	Go to next page
	Modify parameter			Exit without saving the configuration	

ENTER THE SETUP		EXIT THE SETUP	
Push for 2 seconds		Push for 2 seconds	
Using the keys or select SET from the menu	<pre> ELECTREX PAGE XXXX D6 ADDR 247 STAT VER X.XX SET SN XXXXXXXX RESET MAC XXXXXXXXXXXX MEAS </pre>		
Push the key			

SETUP SEQUENCE

PAGE	PARAMETERS	VALUES AVAILABLE	DEFAULT
PASSWORD			
	PASSWORD	0000 ... 9999	0000
MEAS-A Note n.1			
MEAS-A	NET	3P-4W, 2P-2W, 1P-2W, 3P-3W, 3I	3P-4W
NET 3P-4W / EXP	EXPORT	IMP / EXP	EXP
CT 00005 / 5	CT	10000/1 or 5	5/5
VT 000001 / 001	VT	400000/300	1/1
MEAS-B Note n.2			
MEAS-B	I AVG	1...60 (minutes)	8
I AVG 8	P AVG	1...60 (minutes)	15
P AVG 15			
RS485-A Note n.3			
RS485-A	MODE	SLAVE, MASTER	MASTER
MODE SLAVE	TOUT	100...10000 (ms)	3000
TOUT 03000	RETR	1...9	3
RETR 3			
RS485-B			
RS485-B	ADDR (485 address)	1 ... 247	247
ADDR 247	COM1 (Baud rate)	2400, 4800, 9600, 19200, 38400, 56000, 57600, 115200	38400
COM1 38400 / 8	COM1 (Data Bit)	5 ... 8	8
COM2 N / 2	COM2 (Parity)	N = no parity, E = even parity, O = odd parity	N
ST 0150	COM (Stop bit)	1 or 2	2
	S.T. (Silent Time)	0 ... 5000 mS	150
ETH Note n.4			
ETH	DHCP	N, Y	N
DHCP N	IP	xxx.xxx.xxx.xxx	192.168.027.001
IP 192.168.027.001	NETM	xxx.xxx.xxx.xxx	255.255.255.000
NETM 255.255.255.000	GWAY	xxx.xxx.xxx.xxx	127.000.000.001
GWAY 127.000.000.001			
WIFI Note n.4			
WIFI	DHCP	N, Y	N
DHCP N	IP	xxx.xxx.xxx.xxx	192.168.026.001
IP 192.168.026.001	NETM	xxx.xxx.xxx.xxx	255.255.255.000
NETM 255.255.255.000	GWAY	xxx.xxx.xxx.xxx	127.000.000.001
GWAY 127.000.000.001			
NET Note n.5			
NET	DEF	ETH, WIFI	ETH
DEF ETH	ETH	N, Y	Y
ETH Y	WIFI	N, Y	Y
WIFI Y			
LCD Note n.6			
LCD	DIM	DISABLE, ENABLE	DISABLE
DIM DISABLE	TIME	1...90 (sec)	3
TIME 3	LIGHT	0...99	50
LIGHT 50	PULSE	DISABLE, ENABLE	ENABLE
PULSE ENABLE			
ALARM 1 / A Note n.7			
ALARM 1-A	MODE	NORMAL, 1-OF-3, 3-OF-3, UNBAL%, DERIV, UNBAL	NORMAL
MODE NORMAL	TYPE	MIN, MAX	MAX
TYPE MAX	MEAS (note n.5)	Controlled measure. See table n.1 for register selection	000
MEAS 000	THRE (note n.5)	Threshold value	+000.000
THRE +000.000			
ALARM 1 / B Note n.8			
ALARM 1-B	HYST	0...99 (%)	05
HYST 05	DEL	0...99 / S / M / 0...99 / S / M	01 / S / 01 / S
DEL 01 / S / 01 / S	AVG	1...99 (sec)	05
AVG 05	OUT	NORMAL, PULSE-S, PULSE-L, HOLD	NORMAL
OUT NORMAL			
ALARM 2 / A (see ALARM 1/A)			
ALARM 2 / B (see ALARM 1/B)			
ALARM 3 / A (see ALARM 1/A)			

ALARM 3 / B (see ALARM 1/B)			
ALARM 4 / A (see ALARM 1/A)			
ALARM 4 / B (see ALARM 1/B)			
CHANGE PWD			
	PWD	0000...9999	0000

RESET

The "RESET" page allows to reset the total (TOT) and partial (PAR) energy counters, the minimum and maximum values (MAX) and the historical maximum values (MD).

ELECTREX		STAT
KILO D6 ADDR 247	VER X.XX	SET
SN XXXXXXXX	MAC XXXXXXXXXXXX	RESET
		MEAS
		HARM


STAT

The "STAT" page shows the assigned IP address of the LAN and WI-FI port (if present)

ELECTREX	HARM	ETH
KILO D6 ADDR 247	VER X.XX	ETH 192.168.027.001
SN XXXXXXXX	MAC XXXXXXXXXXXX	WIFI 192.168.026.001

TABLE n.1 - Part of ModBus Registers; for e.g. alarm configuration. (Contact us for the full list).

REGISTER	DESCRIPTION	SYMBOL	UNIT
218	Frequency of U1N	f	[Hz]
220	Phase to Neutral Voltage, RMS Amplitude	U1N	[V]
222	Phase to Neutral Voltage, RMS Amplitude	U2N	[V]
224	Phase to Neutral Voltage, RMS Amplitude	U3N	[V]
226	Phase to Phase Voltage, RMS Amplitude	U12	[V]
228	Phase to Phase Voltage, RMS Amplitude	U23	[V]
230	Phase to Phase Voltage, RMS Amplitude	U31	[V]
232	Phase Current, RMS Amplitude	I1	[A]
234	Phase Current, RMS Amplitude	I2	[A]
236	Phase Current, RMS Amplitude	I3	[A]
238	Neutral Current, RMS Amplitude	IN	[A]
240	Phase Active Power (Imp/ Exp)	P1	[W]
242	Phase Active Power (Imp/ Exp)	P2	[W]
244	Phase Active Power (Imp/ Exp)	P3	[W]
246	Phase Reactive Power (Imp/ Exp)	Q1	[var]
248	Phase Reactive Power (Imp/ Exp)	Q2	[var]
250	Phase Reactive Power (Imp/ Exp)	Q3	[var]
252	Phase Apparent Power	S1	[VA]
254	Phase Apparent Power	S2	[VA]
256	Phase Apparent Power	S3	[VA]
258	Phase Power Factor (Imp/ Exp)	PF1	[-]
260	Phase Power Factor (Imp/ Exp)	PF2	[-]
262	Phase Power Factor (Imp/ Exp)	PF3	[-]
270	Phase to Neutral Voltage, Mean RMS Amplitude	UI	[V]
272	Phase to Phase Voltage, Mean RMS Amplitude	UD	[V]
274	Three phase current, RMS Amplitude	I	[A]
276	Total active power (Imp/ Exp)	PS	[W]
278	Total reactive power (Imp/ Exp)	QS	[var]
280	Total apparent power	SS	[VA]
282	Total power factor (Imp/ Exp)	PFS	[-]
332	Phase Current, RMS Amplitude, AVG	I1 AVG	[A]
334	Phase Current, RMS Amplitude, AVG	I2 AVG	[A]
336	Phase Current, RMS Amplitude, AVG	I3 AVG	[A]
344	Total imported active power, AVG	P Imp AVG	[W]
346	Total imported inductive power, AVG	Qind Imp AVG	[var]
348	Total imported capacitive power, AVG	Qcap Imp AVG	[var]
350	Total imported apparent power, AVG	S Imp AVG	[VA]
352	Total exported active power, AVG	P Exp AVG	[W]
354	Total exported inductive power, AVG	Qind Exp AVG	[var]
356	Total exported capacitive power, AVG	Qcap Exp AVG	[var]
358	Total exported apparent power, AVG	S Exp AVG	[VA]

NOTE n.1		
NET	3PH-3W 3PH-4W 2PH-2W 1PH-2W 3l	2 phases 3 wires, Triangle 3 phases 4 wires, Star 2 phases 2 wires, Bi-phase 1 phase, 2 wires, Single phase 3 phases
CT	Primary / Secondary of the current transformer (CT)	
VT	Primary / Secondary of the voltage transformer (VT)	
NOTE n.2		
PAVG	Integration time for Power of the average value (AVG) and peak value (MD)	
I AVG	Integration time for Current of the average value (AVG) and peak value (MD)	
NOTE n.3		
MODE	SLAVE MASTER	RS485 port set as Slave of the network. RS485 port set as Master of the network.
TOUT		Predetermined time in which a given operation must be terminated
RETR		Number of communication attempts on the RS485 port
NOTE n.4		
DHCP	Enable / Disable the search for a DHCP server in the network	
IP	IP address of the network interface	
NETM	Subnet mask: defines the belonging range of a host within an IP subnetwork	
GWAY	IP address of the gateway	
NOTE n.5		
DEF	Selects the default network interface to be used for the communication	
ETH	Enable / Disable the Ethernet (LAN) port	
WIFI	Enable / Disable the WIFI port	
NOTE n.6		
DIM	Enable / Disable dimming of the display	
TIME	Time in seconds after which the display luminosity is reduced. (With DIM enabled)	
LIGHT	Luminosity level of the display	
PULSE	Enable / Disable the flashing of the sine wave symbol  light near the Electrex logo.	
NOTE n.7		
MODE	NORMALE 1-OF-3 3-OF-3 DERIV UNBAL	Classic Alarm with reference to a fixed threshold or to maximum and minimum delay and applicable hysteresis. "AVG" parameter is not used. Considers also the 2 following registers of the selected one in "MEAS". It operates on a fixed max or min threshold with delay and applicable hysteresis. If one of the three registers exceeds the threshold the alarm goes ON. "AVG" parameter is not used. Considers also the 2 following registers of the selected one in "MEAS". It operates on a fixed max or min threshold with delay and applicable hysteresis. When all the three registers exceed the threshold the alarm goes ON. "AVG" parameter is not used. "THRE" parameter becomes a % value, "AVG" parameter is used. The instant value applied to the alarm on "MEAS" is compared with its value mediated obtained on the basis of the time set on "AVG". When the instantaneous value combined alarm differs in more (setting "Max") or less (setting "MIN") from the average value ("AVG") of the percentage set on "THRE" the alarm goes on. With delay and applicable hysteresis. Considers also the 2 following registers of the selected one in "MEAS". "THRE" parameter becomes a % value. Alarm goes on when one of the three register is different from the percentage set on "THRE" comply with the higher value of the three read register if "MAX" is set on "TYPE", or comply with the lower value of the three register if "MIN" is set on "TYPE" With delay and applicable hysteresis.
TYPE	MAX MIN	Alarm setting in excess or in decrease compared with the predefined conditions. With the exception of "UNBAL and UNBAL%".
MEAS		Indicates which register (measure) the alarm is related to. See table N.1 Input Register.
THRE		Alarm threshold in absolute value, with the exception made for "DERIV" and "UNBAL" in which the value inserted becomes a percentage.
NOTE n.8		
HYST		Hysteresis, or the cycle between alarm value and alarm return value. It is a particularly useful function to avoid unwanted oscillations and / or alarms. Example: Alarm on current set at 100 A Max with 5% hysteresis. The alarm is activated at 100 A and is deactivated at 95 A
DEL		Delay time (between 1 sec and 99 min) for activation. Delay time (between 1 sec and 99 min) for deactivation.
AVG		Parameter to be used in "DERIV" mode only. Moving window width (in secs) used to create a reference value with which to compare the instantaneous data
OUT	NORMAL HOLD PULSE-L PULSE-S	Alarm remains active during the duration of the event. It restores automatically. Alarm remains active until the manual reset via Modbus. Generates a 500ms impulse when the alarm goes on. Generates a 100ms impulse when the alarm goes on.


INPUTS - OUTPUTS

SETUP SEQUENCE

PAGE	PARAMETERS	VALUES AVAILABLE	DEFAULT
COUNT WEIGHT Note A1			
COUNT WEIGHT	IN1		+00001.000
	IN2		+00001.000
ABOUNCE CLOSE Note A2			
ABOUNCE CLOSE	IN1	1, 5, 50 (ms)	5
	IN2	1, 5, 50 (ms)	5
ABOUNCE OPEN Note A2			
ABOUNCE OPEN	IN1	1, 5, 50 (ms)	5
	IN2	1, 5, 50 (ms)	5
INVERT STATUS Note A3			
INVERT STATUS	IN1	N, Y	N
	IN2	N, Y	N
PULSE OUT Note A4			
PULSE OUT	OUT1	N, Y	N
	OUT2	N, Y	N
NORM CLOSE Note A5			
NORM CLOSE	OUT1	N, Y	N
	OUT2	N, Y	N
PULSE WIDTH Note A6			
PULSE WIDTH	OUT1	50...1000 (ms)	100
	OUT2	50...1000 (ms)	100

OUTPUTS		INPUTS	
19	C1 Common 1 (negative)	10	C2 Common 2 (negative)
20	O1 Output 1 (positive)	11	I2 Input 2 (positive)
21	C2 Common 2 (negative)	12	C1 Common 1 (negative)
22	O2 Output 2 (positive)	13	I1 Input 1 (positive)

OUTPUTS		INPUTS	
Maximum applicable voltage:	27 Vdc	Supply voltage (external):	from 10 to 30 Vdc
Maximum switchable current:	27mA	Current consumption:	from 2 to 10mA
		Max. count frequency	10 or 100Hz
N.B. Transistor optocoupler digital outputs (NPN) according to DIN 43864.		N.B. For gas meters a galvanic separation is needed per ATEX standards	




NOTE A1	Count Weight	Input Weight
NOTE A2	Abounce close	Anti-bounce setting on contact closure
	Abounce open	Anti-bounce setting on contact opening
NOTE A3	Invert Status	Inverts the input status
NOTE A4	Pulse Out	If set to "Y", set the output as an impulsive one.
NOTE A5	Norm Close	Set the output as normally closed.
NOTE A6	Pulse Width	Output pulse duration


VOLTAGE CONNECTION

Use cables with max cross-section of 2,5 mm² if stranded, 4 mm² if rigid and connect them to the clamps marked VOLTAGE INPUT on the instrument according to the applicable diagrams that follow.


1P2W




3I




3P4W / 3I



2P2W




3P3W




CURRENT CONNECTION

Connect the CT outputs to the terminals marked I1, I2, I3 (CURRENT INPUT) of the instrument according to the applicable diagrams that follow.


1P2W / 2P2W



3P3W



3P3W / 3P4W / 3I



Note: Scrupulously respect the matching of phase between the voltage signals and current signals. Failure to comply with this correspondence and connection diagrams gives rise to measurement errors.

DIP-SWITCH CONFIGURATION

DIP	FUNCTION	SLAVE	MASTER *
1	Line termination resistance (120 Ohm)	OFF	ON
2	Fail safe resistance B (-)	OFF	ON
3	Fail safe resistance A (+)	OFF	ON
4	Not used	OFF	OFF

* with RS-485 Master PUK activated

LAN 10/100 ETHERNET PORT




ETHERNET

The instrument is equipped with a Ethernet Lan 10/100 Auto-MDI/MDIX port. For the connection can be used a data cable straight or crossover.

Note: the port is not a PoE (Power over Ethernet = device power supply via the Lan port) type. The connection of the device to a PoE port is anyway accepted. The power supply anyway must be always provided by an external power supplier.

EXPBUS PORT



The ExpBus port, configurable via Ethernet port on web pages:
 - uses a multicast communication rated at 250kb/sec with collision management
 - max cable length : 10 meters
 - manages up to 16 modules (but technically can manage up to 126)
 - uses the UTP cable, 4 wires used:
 2 for the power supply at 9 Vdc
 2 for the bidirectional communication
 The modules will also power supply the ExpBus port
 The cable must be connected in in-out modality (multidrop) as per the RS485 Bus.


MESSAGE "CFG ERROR"

During the set up operation a "CFG ERROR" message could appear. This means that some wrong parameters are typed.

CFG ERROR

POWER SUPPLY


The instrument is equipped with a separate power supply. The power supply terminals are numbered (17) and (18). Use cables with max cross-section of 2,5 mm² if stranded, 4 mm² if rigid.



POWER SUPPLY

1	85/265Vac +/- 10% 50/60Hz
2	F: 500 mA T

SERIAL LINE CONNECTION



Max cable length: 1000 meters.

RS485	
Address	27
Baud rate	38400
Parity	None
Bit of Stop	2